



VAPOUR BARRIER

If you need to install a vapour barrier, we recommend using polyethylene plastic sheeting. The vapour barrier must be placed above the wooden battens, i.e. between the battens and the foot of the rafters. Install the vapour barrier so it is well-stretched and sits tightly against the insulation.


Please refer to the manufacturer's instructions.




TROLDTEKT® V-LINE 2WAY VARIANTS



Trolldtekt® v-line 2way 10




Trolldtekt® v-line 2way 6



Trolldtekt® v-line 2way blank

TROLDTEKT® V-LINE BLANK

V-line 2way blank is without grooves, but the edge design is similar to v-line 2way 6 and v-line 2way 10. The panel can be used, for example, for finishing (1) or for installing lighting etc. (2).



TROLDTEKT® SCREWS

Panel thickness (mm)	Panel length (mm)	Screw dimension (mm)	No. of screws (per panel)	Max. span (mm)
25	1200	4.2 x 45 / 4.2 x 50	6	600

Trolldtekt structure screw for wood and steel, PH2
4.2 x 45 mm



Trolldtekt structure screw for steel, PH2
4.2 x 50 mm



This document reflects Trolldtekt's knowledge of certifications, standards, and products at the time of publication.

No rights can be derived from this document.
Changes, typesetting and printing errors reserved.

The most recent version can be found online by scanning the QR code.

JANUARY 2026 EN V01

Trolldtekt A/S
Sletvej 2A
DK - 8310 Tranbjerg J
Tel. +45 8747 8100
info@trolldtekt.dk
www.trolldtekt.com