


INSTALLATION INSTRUCTIONS

for Troldekt® v-line 1way, installed with screws


These instructions apply to the installation of Troldekt® v-line 1way with screws on wooden battens or steel profile system. If you install Troldekt® on wooden battens, the battens should be min. 22 x 95 mm. Download installation instructions for the Troldekt® C60 profile system or wooden battens from www.troldekt.com.

PROFILE DRAWING (INDEPENDENT OF SUSPENSION)


CROSS SECTION v-line 1way 10




CROSS SECTION v-line 1way blank



CROSS SECTION v-line 1way 6



LONGITUDINAL SECTION v-line 1way 10, 6 and blank



INSTALLATION (PLEASE READ THE FULL INSTRUCTIONS BEFORE STARTING WORK)

1: Start by installing a complete row of Troldekt panels along the centre line of the room. Then continue along both sides. It is important that the panels are butted tightly up against one another during installation. For best aesthetic results, the panels should be installed in broken bond.

2: Fix the panels using Troldekt screws spaced 25/20 mm from the edges – as

shown in the illustrations below: 25 mm for wooden battens, 20 mm for C60 steel profiles. Be careful not to over-drive the screws and so cause an indentation in the panel.

The screws should be screwed into the main surface of the panel (**Fig. 1**) – not into the bottom of the grooves (**Fig. 2**).






ILLUSTRATION - INSTALLATION




VAPOUR BARRIER

If you need to install a vapour barrier, we recommend using polyethylene plastic sheeting. The vapour barrier must be placed above the wooden battens, i.e. between the battens and the foot of the rafters. Install the vapour barrier so it is well-stretched and sits tightly against the insulation.


Please refer to the manufacturer's instructions.




TROLDTEKT® V-LINE 1WAY VARIANTS



Troldekt® v-line 1way 10



Troldekt® v-line 1way 6




Troldekt® v-line 1way blank

TROLDTEKT® V-LINE BLANK

V-line 1way blank is without grooves, but the edge design is similar to v-line 1way 6 and v-line 1way 10.

The panel can be used, for example, for finishing (1) or for installing lighting etc. (2).



TROLDTEKT® SCREWS

Panel thickness (mm)	Panel length (mm)	Screw dimension (mm)	No. of screws (per panel)	Max. span (mm)
25	1200	4.2 x 45 / 4.2 x 50	6	600

Troldekt structure screw for wood and steel, PH2
4.2 x 45 mm



Troldekt structure screw for steel, PH2
4.2 x 50 mm



This document reflects Troldekt's knowledge of certifications, standards, and products at the time of publication.

No rights can be derived from this document.
Changes, typesetting and printing errors reserved.

The most recent version can be found online by scanning the QR code.

JANUARY 2026 EN V01

Troldekt A/S
Sletvej 2A
DK - 8310 Tranbjerg J
Tel. +45 8747 8100
info@troldekt.dk
www.troldekt.com